SAMSUNG

FREE STANDING RANGE

BASIC: FTQ353IWUX
MODEL: NE595R0ABSR
MODEL CODE: NE595R0ABSR

SERVICE Manual

ELECTRIC RANGE

CONTENTS

1. Precaution
2. Product Specification
3. Disassembly and Reassembly
4. Troubleshooting
5. PCB Diagrams
6. Wiring Diagrams
7. Schematic Diagrams

Refer to the service manual in the GSPN(see rear cover) for the more information.

• Contents

1. Precaution 3
1-1 Forward 3
1-2 Safety Precautions 3
1-3 Important Safety Instructions 4
1-4 Model & Serial Number Label and Tech Sheet Locations 6

2. Specifications 7
2-1 Features 7
2-2 Table of Specifications 9
2-3 Accessory 10

3. Disassembly and Reassembly 11
3-1 Removing Cover-Back Main Wire, Cover-Back Guard Wire and PCB-Main 11
3-2 Removing Regulator-Energy 12
3-3 Removing Surface elements and The Ceramic Glass Cooktop 13
3-4 Removing The Latch-Door & Switch-Door Plunger 15
3-5 Removing Heater-Broil 16
3-6 Removing Heater-Bake 17
3-7 Removing Convection Element, Fan-Covnection and Motor-Convection 18
3-8 Removing Lamp 19
3-9 Removing Sensor-Thermistor 20
3-10 Removing Assy-Drawer 21
3-11 Removing and Replacing Oven Door 22
3-12 Removing Handle-Door and Glass-Inner 23
3-15 Removing Gasket-Door 26
3-16 Removing The Panel-Side 27

4. Troubleshooting 28
4-1 Failure Display Codes 28
4-2 Electrical Malfunction 40

5. PCB Diagrams 59
5-1 PCB Diagrams (Main) 59
5-2 PCB Diagrams 60

6. Wiring Diagrams 61
6-1 Wiring Diagrams 61

7. Schematic Diagrams 62
7-1 Schematic Diagrams 62
7-1 Schematic Diagrams 63

NE595R0ABSR.indb 2 2012-02-22 □□ 10:53:00

1. Precaution

1-1 Forward

This SAMSUNG Service Manual, “ 30” Freestanding Self-Cleaning Electric Range,” provides the technician with information on the operation and service of the Freestanding Self-Cleaning Electric Range. It is to be used as a training Service Manual. For specific information on the model being serviced, refer to the “Owner’s Manual” or “Tech Sheet” provided with the electric range.

1-2 Safety Precautions

- Repairs of the appliance should be carried out by a licensed technician only. Incorrect repairs may result in dangerous situations. If you need repairs, contact an SAMSUNG Service Center or your dealer.
- If the power cord is defective, it must be replaced by a qualified service agent with a UL listed range cord.
- Electrical leads and cables should not be allowed to touch the oven.
- Rating plate is located on the left side of warming drawer.
- The power supply of the appliance should be turned off when it is being repaired.

WARNING

- To avoid risk of severe personal injury or death, disconnect power before working/servicing on appliance to avoid electrical shock.
- When the oven operates, the interior parts will be very hot.

SAMSUNG Electronices assumes no responsibility for any repairs made on our products by anyone other than Authorized Service Technicians.

NE595R0ABSR.indb 3 2012-02-22 10:53:00

1-3 Important Safety Instructions

Read and follow all instructions before using your oven to prevent the risk of fire, electric shock, injury to person, or damage when using the range. This guide don't cover all possible conditions that may occur. For further assistance contact your service agent or manufacturer.

WARNING

This symbol will help alert you to hazards or unsafe practices which could cause serious bodily harm or death.

- Be sure your appliance is properly installed and grounded by a qualified technician.
- Do not repair or replace any part of the appliance unless specifically recommended in the manual. All other servicing should be referred to a qualified technician.
- Always disconnect power to appliance before servicing by removing the fuse or switching off the circuit breaker

WARNING

- INJURIES CAN OCCUR IF THE RANGE TIPS
- INSTALL ANTI-TIP DEVICE PACKED WITH RANGE

- FOLLOW ALL INSTALLATION INSTRUCTIONS

To reduce the risk of tipping of the range, the range must be secured by properly installed anti-tip devices. To check if the bracket is installed properly,

- Warming drawer : grasp the top rear edge of the Range and carefully attempt to tilt it forward. verify that the anti-tip devices are engaged.
- Storage drawer : Remove drawer and verify leveling leg is inserted into and fully secured by the anti-tip devices.

Refer to the installation manual for proper anti-tip bracket installation.

- Do not step, lean or sit on the doors of the range -this can cause the range to tip, resulting in burns or serious injuries.

WARNING

- **DO NOT TOUCH HEATING ELEMENTS OR INTERIOR SURFACES OF OVEN** – Heating elements may be hot even though they are dark in color. Interior surfaces of an oven become hot enough to cause burns. During and after use, do not touch, or let clothing or other flammable materials contact heating elements or interior surfaces of oven until they have had sufficient time to cool. Other surfaces of the appliance may become hot enough to cause burns – among these surfaces are oven vent openings and surfaces near these openings, oven doors, and windows of oven doors.

CAUTION

Do not store items of interest to children in cabinets above a range or on the back guard of a range – children climbing on the range to reach items could be seriously injured.

- Do Not Leave Children Alone - Children should not be left alone or unattended in area where appliance is in use. They should never be allowed to sit or stand on any part of the appliance.
- Never Use Your Appliance for Warming or Heating the Room.
- Storage in or on Appliance – Flammable materials should not be stored in an oven or near surface units. Be sure all packing materials are removed from the appliance before operating it. Keep plastics, clothes and paper away from parts of the appliance that may become hot
- Wear Proper Apparel – Loose-fitting or hanging garments should never be worn while using the appliance.
- Do Not Use Water on Grease Fires – Turn off oven to avoid spreading the flame. Smother the fire or flame by closing the door or use dry chemical, baking soda or foam- type extinguisher.
- Use Only Dry Potholders – Moist or damp potholders on hot surfaces may result in burns from steam. Do not let potholder touch hot heating elements. Do not use a towel or other bulky cloth.

WARNING

SURFACES

- **DO NOT TOUCH SURFACE UNITS OR AREAS NEAR UNITS** – Surface units may be hot even though they are dark in color. Areas near surface units may become hot enough to cause burns. During and after use, do not touch, or let clothing or other flammable materials contact surface units or areas near units until they have had sufficient time to cool. Among these areas are the cook-top and surfaces close to the cook-top.

WARNING

To avoid risk of electrical shock, personal injury, or death, make sure your range has been properly grounded and always disconnect it from main power supply before any servicing.

NE595R0ABSR.indb 4 2012-02-22 10:53:00

1. Precaution

SURFACE COOKING UNITS

- **Use Proper Pan Size** – This appliance is equipped with one or more surface units of different sizes. Select utensils having flat bottoms large enough to cover the surface unit heating element. The use of undersized utensils will expose a portion of the heating element to direct contact and may result in ignition of clothing. Proper relationship of utensil to burner will also improve efficiency.
- **Never Leave Surface Units Unattended at High Heat Settings** – Boil overs may cause smoking and greasy spillovers may ignite.
- **Make Sure Reflector Pans or Drip Bowls Are in Place** – Absence of these pans or bowls during cooking may subject wiring or components underneath to damage.
- **Protective Liners** – Do not use aluminum foil to line surface unit drip bowls or oven bottoms, except as suggested in the manual. Improper installation of these liners may result in a risk of electric shock, or fire.
- **Glazed Cooking Utensils** – Only certain types of glass, glass/ceramic, ceramic, earthenware, or other glazed utensils are suitable for range-top service without breaking due to the sudden change in temperature.
- **Utensil Handles Should Be Turned Inward and Not Extend Over Adjacent Surface Units** – To reduce the risk of burns, ignition of flammable materials, and spillage due to unintentional contact with the utensil, the handle of a utensil should be positioned so that it is turned inward, and does not extend over adjacent surface units.
- **Do Not Soak Removable Heating Elements** – Heating elements should never be immersed in water.
- Be sure you know which control pads operate each surface unit. Make sure you turned on the correct surface unit.

SELF-CLEAN OVENS

- **Do Not Clean Door Gasket** – The door gasket is essential for a good seal. Care should be taken not to rub, damage, or move the gasket.
- **Do Not Use Oven Cleaners** – No commercial oven cleaner or oven liner protective coating of any kind should be used in or around any part of the oven.
- **Clean in the self-clean cycle only parts listed in this manual**. Before self-cleaning the oven, remove the broiler pan and any utensils from the oven.
- **Never keep pet birds in the kitchen** – the health of birds is extremely sensitive to the fumes released during an oven selfclean cycle. Fumes may be harmful or fatal to birds. Move birds to well-ventilated room.
- **Important Instruction** – In the event the self-clean mode “F” code goes on, or three long beeps sound, oven is malfunctioning in the self-clean mode. Turn off or disconnect appliance from power supply and have serviced by a qualified technician.

VENTILATING HOODS:

- **Clean Ventilating Hoods Frequently** – Grease should not be allowed to accumulate on hood or filter.
- **When flaming foods under the hood, turn the fan on.**

OVEN

- **Use Care When Opening Door** – Let hot air or steam escape before you remove or replace food in the oven
- **Do Not Heat Unopened Food Containers** – Build-up of pressure may cause container to burst and result in injury.
- **Keep Oven Vent Ducts Unobstructed** – the oven vent is located above the left rear surface unit. this area could become hot during oven use. Never block this vent and never place plastic or heatsensitive items on vent
- **Placement of Oven Racks** – Always place oven racks in desired location while oven is cool. If rack must be moved while oven is hot, do not let potholder contact hot heating element in oven.
- **Do Not** allow aluminum foil or meat probe to contact heating elements.

GLASS/CERAMIC COOKING SURFACES

- **Do Not Cook on Broken Cook-Top** – If cook-top should break, cleaning solutions and spillovers may penetrate the broken cooktop and create a risk of electric shock. Contact a qualified technician immediately.
- **Clean Cook-Top With Caution** – If a wet sponge or cloth is used to wipe spills on a hot cooking area, be careful to avoid steam burn. Some cleaners can produce noxious fumes if applied to a hot surface.

DEEP FAT FRYERS:

- Use extreme caution when moving the grease kettle or disposing of hot grease.

NE595R0ABSR.indb 5 2012-02-22 10:53:00

1-4 Model & Serial Number Label and Tech Sheet Locations

This Model / Serial Number label and Tech Sheet locations are shown below.
The rating plate is located above the drawer on the oven frame.



NE595R0ABSR.indb 6 2012-02-22 10:53:02

2. Specifications

2-1 Features

Features



Surround Air-vection



- Main Convection Fan with 2-Sub.Fans makes complex small Swirl.
- Optimal Heat Distribution and Even Cook Performance.
- Updated Control Algorithm (for the Swirl Improvement of Door Front/Left/Lower)

Easy Steam Cleaning

- More Efficiency & Time Saving
- Available for Water and Oven Washing Liquid (Water + Detergent)
- Takes about 20minutes to Clean-out easily
- Steam fits Light and frequent cleaning,
  (Pyrolitic Self-cleaning fits Greasy dirt cleaning)

NE595R0ABSR.indb 7 2012-02-22 □□ 10:53:02

2. Specifications

Features	
Item	Steam Clean
How to Use	- Pour the water 10oz (+detergent) - Push the steam cleaning button - In around half min, the oven will stop automatically. - Wipe it out with wet cloths.
Operating (Temperature)	About 70 ºC
Operating Time	20 Minutes
Used Heater	Bottom Baked Heater
Smell	No smell
Tool to clean	Wet cloths
	
Biggest Capacity - The biggest capacity in current US market !!! - It benefits consumers to cook for large family food in Thanksgiving & Christmas seasons (i.e Turkey 25 lbs = 4.4 cu ft, 20 lbs = 3.5 cu ft)	

NE595R0ABSR.indb 8 2012-02-22 □□ 10:53:02

2. Specifications

2-2 Table of Specifications

Items		Model	
		BASIC MODEL	NEW MODEL
Model Name		FTQ353IWUX	NE595R0ABSR
Category		Convection	Convection
Overall	Width	30”	30”
	Installation type	Freestanding	Freestanding
	Color availability	STS, WH, BK	STS, WH, BK
Control	Oven	Keypad	Keypad
	Cooktop	Knob	Knob
	Display	LED	LED
	Electronic clock	Yes	Yes
	Control lock capability	Yes	Yes
	Audible preheat signal	Yes	Yes
Cooktop	Material	Ceramic glass	Ceramic glass
	# of element	5	5
Power	LR	6”-1,200W	6”-1,200W
	RR	6”-1,200W	6”-1,200W
	CR	Warming Center (100W)	Warming Center (100W)
	LF	Dual(6”/9”-1,200/2,500W)	Dual(6”/9”-1,400/3,000W)
	RF	Dual(6”/9”-1,200/2,500W)	Dual(9/12”-1,900/3,000W)
Oven	Capacity(cu.ft)	5.9	5.9
	Broil element	3800 watts	3800 watts
	Bake element	3000 watts	2400 watts
	Convection System	Yes	Yes
	# of Racks	2	2
	Interior oven light	120V, 40 watts	120V, 40 watts
	Cleaning	Self clean & Steam clean	Self clean & Steam clean
Drawer	Type	Warming drawer	Storage drawer
	Element	600 watts	-
Dimensions (inch)	Oven Interior(W x H x D)	24 1/2 x 20 1/4 x 19 3/8	24 1/2 x 20 1/4 x 19 3/8
	Exterior - Width	29 7/8	29 7/8
	Exterior - Height	36 (cooktop), 47 5/8 (backguard top)	36 (cooktop), 47 5/8 (backguard top)
	Exterior - Depth	25 11/16 (Door), 28 (with handle)	25 11/16 (Door), 28 (with handle)
	Net weight: Lbs (Kg)	181 lbs (82kg)	176 lbs (80kg)
Power	Rating(240V 60Hz)	Range : 4500W Cooktop : 7500W	Range : 4600W Cooktop : 8500W

NE595R0ABSR.indb 9 2012-02-22 □□ 10:53:02

2. Specifications

2-3 Accessory

Item	Description	Code No.	Q'ty
	Rack Flat	DG75-01001B	2

NE595R0ABSR.indb 10 2012-02-22 □□ 10:53:03

3. Disassembly and Reassembly

3-1 Removing Cover-Back Main Wire, Cover-Back Guard Wire and PCB-Main

WARNING

ELECTRICAL SHOCK HAZARD

Disconnect power before servicing the range. Replace all panels before operating range. Failure to do so can result in death or electrical shock.

PRECAUTION

When you work on the electric range, be careful when handling the sheet metal parts. Sharp edges may be present, and you can cut yourself if you are not careful.

Parts	Explanation Photo	Explanation
Cover-Back Main Wire, Cover-Back Guard Wire and PCB-Main		1. Turn off the electrical supply going to the range. 2. Pull the range away from the wall so that you can access the rear panel. 3. Remove the 8 screws from the Cover-Back Main Wire and remove the panel.
		4. Remove 3 screws from the Cover-Back Guard Wire and remove the cover. 5. Remove 2 screws of PCB Main and separate PCB Main.
		**REASSEMBLY NOTE:** When you remove(replace) membrane tail from the connector, pullthe actuator fully

NE595R0ABSR.indb 11 2012-02-22 10:53:04

3-2 Removing Regulator-Energy

WARNING

Disconnect power before servicing the range Replace all panels before operating range. Failure to do so can result in dearh or electrical shock.

PRECAUTION

When you work on the electric range, be careful when handling the sheet metal parts. Sharp edges may be present, and you can cut yourself if you are not careful.

Parts	Explanation Photo	Explanation
 Regulator-Energy		**1.** Turn off the electrical supply going to the range. **2.** Pull the range away from the wall so that you can access the rear panel. **3.** Remove Cover-Back Guard Wire. (See step 4 on page 11)
		**4.** Remove Regulator-Energy connectors which be replaced.
		5. Pull out the Knob-Dial.
	 2 Screws	**6.** Remove 2 screws and replace Regulator-Energy.

* Reassembly of All part is the reverse order of disassembly.

Screw
- Terminal Block Screw : M4 X 18.
- The others : M4 X 12.

NE595R0ABSR.indb 12 2012-02-22 10:53:04

3-3 Removing Surface elements and The Ceramic Glass Cooktop

WARNING

ELECTRICAL SHOCK HAZARD

Disconnect power before servicing the range. Replace all panels before operating range. Failure to do so can result in death or electrical shock..

<table>
<tr><th>Parts</th><th>Explanation Photo</th><th>Explanation</th></tr>
<tr><td rowspan="4">
Surface elements and Ceramic Glass Cooktop</td><td>  </td><td>1. Unplug the cord or disconnect power
2. Open oven door and remove the 3 screws located at the front of the cook-top, then close the door.</td></tr>
<tr><td>  </td><td></td></tr>
<tr><td colspan="2">3 Slightly lift up and pull up the cook-top and then unplug the 2 connectors wire at the back by squeezing side tabs and unscrew ground wire.</td></tr>
<tr><td>  </td><td>4. Protect the cooktop surface and turn the assembly over.</td></tr>
</table>

NE595R0ABSR.indb 13 2012-02-22 10:53:05

3-3 Removing Surface elements and The Ceramic Glass Cooktop

Parts	Explanation Photo	Explanation
Surface elements and Ceramic Glass Cooktop		**5.** To remove the surface elements **a)** Remove the wires from the element and limiter terminals. **b)** Remove the element bracket screw (shown above) for the element you are servicing. **c)** Carefully lift the bottom of the bracket just far enough to remove the element. **d)** Use sharp tool to remove the heating element. **REASSEMBLY NOTE**: When you reinstall the element make sure that the wires are inserted into the correct tap then reinstall the bracket screw to secure it to the cooktop.

* Reassembly of All part is the reverse order of disassembly.

Screw
- Terminal Block Screw : M4 X 18.
- The others : M4 X 12.

NE595R0ABSR.indb 14 2012-02-22 10:53:05

3-4 Removing The Latch-Door & Switch-Door Plunger

WARNING

ELECTRICAL SHOCK HAZARD

Disconnect power before servicing the range. Replace all panels before operating range. Failure to do so can result in death or electrical shock.

CAUTION

When you work on the electric range, be careful when handling the sheet metal parts. Sharp edges may be present, and you can cut yourself if you are not careful.

Parts	Explanation Photo	Explanation
Latch-Door & Switch-Door Plunger		**1.** Turn off the electrical supply going to the range. **2.** Open the oven door. **3.** Raise the cooktop (see page 13 for the procedure). **4.** To remove the Latch-Door: a) Remove the 2 screws from the front of cavity.
		b) Remove two screw from Cover-Back Main and remove latch-door
		**5.** To remove the Switch-Door Plunger **a)** Remove the Cover-Back Guard Wire (see page 11 for the procedure). **b)** Release the wire from Cable Clamp. **c)** Remove the Switch-Door Plunger from the range. take out carefully with shaking up and down by using tool.
		

* Reassembly of All part is the reverse order of disassembly.

Screw
- Terminal Block Screw : M4 X 18.
- The others : M4 X 12.

NE595R0ABSR.indb 15 2012-02-22 10:53:07

3-5 Removing Heater-Broil

WARNING

Disconnect power before servicing the range. Replace all panels before operating range. Failure to do so can result in death or electrical shock.

CAUTION

When you work on the electric range, be careful when handling the sheet metal parts. Sharp edges may be present, and you can cut yourself if you are not careful.

Parts	Explanation Photo	Explanation
Broil Heater	 	1. Turn off the electrical supply going to the range. 2. Open the oven door and remove the racks from inside the oven. 3. To remove the broil element. a) Remove the Sensor-Thermistor and 4 screws from the front and rear brackets. b) Remove Cover-Back Main Wire and disconnect 2 wires from Heater-Broil and a wire from Sensor-Thermistor.

* Reassembly of All part is the reverse order of disassembly.

Screw
- Terminal Block Screw : M4 X 18.
- The others : M4 X 12.

NE595R0ABSR.indb 16 2012-02-22 10:53:08

3-6 Removing Heater-Bake

Parts	Explanation Photo	Explanation
Heater-Bake		**1.** Unplug range or disconnect power. **2.** Pull the range out of its mounting location so that you can access the rear of the unit. **3.** Remove Cover-Back Main Wire. (See step 3 on page 11 for procedure) **4.** Remove Terminal-Block and Bracket-Cover Access(with Adiabatic-Terminal) by unscrew 2 points.
		**5.** Unscrew 2 points of Heater-Bake.
		**6.** Cut the Adiabatic-Rear based on the lower side.
		**7.** Carefully pull out Heater-Bake and replace it.

* Reassembly of All part is the reverse order of disassembly.

Screw
- Terminal Block Screw : M4 X 18.
- The others : M4 X 12.

NE595R0ABSR.indb 17 2012-02-22 □□ 10:53:09

3-7 Removing Convection Element, Fan-Covnection and Motor-Convection

Parts	Explanation Photo	Explanation
 Convection Element, Fan-Convection , Motor-Convection	 	**1.** Disconnect power and remove oven racks. **2.** Pull the range out of its mounting location so that you can access the rear of the unit. **3.** Remove Cover-Back Main Wire from the unit. (See step 3 on page 12 for procedure) **4.** Remove oven door. (See Page 25 on page for procedure) **5.** Power Cover-casing **6.** Unscrew 2 screws and remove Bracket-Convection Heater to remove Heater-Convection. **7.** Unscrew nut of Fan-Convection Main. **8.** Unscrew 9 points and disconnect a Motor-Convection wire and disconnect Heater-Convection wire.

CAUTION

Be careful not to bend the Fan-Convection(Blade)

NE595R0ABSR.indb 18 2012-02-22 10:53:10

3-8 Removing Lamp

WARNING

Disconnect power before servicing the range. Replace all panels before operating range. Failure to do so can result in death or electrical shock.

CAUTION

When you work on the electric range, be careful when handling the sheet metal parts. Sharp edges may be present, and you can cut yourself if you are not careful.

Parts	Explanation Photo

Explanation
1. Disconnect power. **2.** Remove oven door. **3.** Turn the glass bulb cover in the oven counterclockwise to remove. **4.** Turn bulb counterclockwise to remove from socket. **5.** Replace bulb and cover by turning clockwise.

Lamp

CAUTION

Be careful not to scratch or chip the oven liner paint when to remove the oven light socket in the next step.

Explanation Photo	Explanation



To replace socket assembly:

6. Disconnect the wires from the socket terminals.

7. Use a screwdriver and bend the clips on the socket away from the edges of the liner hole(there are 6 clips on th e socket), and pull the socket out of the liner. Push the socket out from the rear of the unit.

* Reassembly of All part is the reverse order of disassembly.

Screw
- Terminal Block Screw : M4 X 18.
- The others : M4 X 12.

NE595R0ABSR.indb 19 2012-02-22 □□ 10:53:11

3-9 Removing Sensor-Thermistor

⚠ WARNING

ELECTRICAL SHOCK HAZARD

Disconnect power before servicing the range. Replace all panels before operating range. Failure to do so can result in death or electrical shock.

⚠ PRECAUTION

When you work on the electric range, be careful when handling the sheet metal parts. Sharp edges may be present, and you can cut yourself if you are not careful.

Parts	Explanation Photo	Explanation
Sensor-Thermistor	 	1. Turn off the electrical supply going to the range. 2. Remove oven door and racks from inside the oven. 3. Unscrew Sensor-Thermistor. 4. Remove Cover-Back Main Wire and disconnect a wire from Sensor-Thermistor. 5. Replace the Sensor-Thermistor.

NE595R0ABSR.indb 20 2012-02-22 □□ 10:53:12

3-10 Removing Assy-Drawer

WARNING

ELECTRICAL SHOCK HAZARD

Disconnect power before servicing the range. Replace all panels before operating range. Failure to do so can result in death or electrical shock.

PRECAUTION

When you work on the electric range, be careful when handling the sheet metal parts. Sharp edges may be present, and you can cut yourself if you are not careful.

Parts	Explanation Photo
Assy-Drawer	 

Explanation

To remove Assy-Drawer:

1. CAUTION -Turn power OFF before removing the Warming Drawer.
2. Open the drawer to the fully opened position.
3. Locate glide lever on each side of drawer, push down on the left glide lever and pull up on the right glide lever.
4. Pull out the warning drawer.

NE595R0ABSR.indb 21 2012-02-22 10:53:14

3-11 Removing and Replacing Oven Door

WARNING

The door is very heavy. Be careful when removing door Do not lift door up by the Handle-Door.

Parts	Explanation Photo	Explanation
Oven door		**To remove Oven Door:** **1.** Fully open the door **2.** Pull the hinge locks downward(Fig.1)
		3. Firmly grasp both side of the door at the top. **4.** Close door to the door removal position, which is approximately 5 degrees. (refer to the Fig.2) Lift door up and out until the hinge arm are clear of the slot.
	 	To replace door: **1.** Firmly grasp both sides of the door at the top position.
		2. Fully open the door. (If the door will not fully open, it means that the indentation is not seated correctly in the bottom edge of the slot. Push the hinge locks up to the locked position.) **3.** Close the oven door.

* Reassembly of All part is the reverse order of disassembly.

Screw
- Terminal Block Screw : M4 X 18.
- The others : M4 X 12.

NE595R0ABSR.indb 22 2012-02-22 □□ 10:53:14

3-12 Removing Handle-Door and Glass-Inner

WARNING

ELECTRICAL SHOCK HAZARD

Disconnect power before servicing the range. Replace all panels before operating range. Failure to do so can result in death or electrical shock.

PRECAUTION

When you work on the electric range, be careful when handling the sheet metal parts. Sharp edges may be present, and you can cut yourself if you are not careful.

Parts	Explanation Photo	Explanation
Door		**1.** Remove the oven door from the range (see page 3-10 for the procedure.) **2.** Place the oven door on a padded work surface with the front glass facing down. **3.** Remove 3 bottom screws from the door.
		**4.** Remove 2 Handle-screws from the door.
		5. Lift the door rear assembly off the front assembly.
	 	**6.** Remove 2 spacers and 2 screws.

NE595R0ABSR.indb 23 2012-02-22 10:53:16

3-13 Removing Handle-Door and Glass-Inner

Parts	Explanation Photo	Explanation
Handle Door		**To remove Handle-Door** **1.** Remove 2 screws to remove Handle-Door
Glass-Inner	 	**To remove Glass-Inner** **1.** Remove 6screws from rear side of door to remove 2 Hinge-Door.
	 	**2.** Remove 4screws ro remove Glass-Inner Sub Assembly **3.** Remove 7screws ro remove Baffle-Door

NE595R0ABSR.indb 24 2012-02-22 □□ 10:53:16

3-14 Removing Handle-Door and Glass-Inner

Parts	Explanation Photo
Handle Door	 
	Explanation
	4. Remove Baffle-Door and take out the Glass-Inner assembly.
	Explanation Photo
	 
	Explanation
	5. Unfold 2 flanges of Cover-Frame Inner Glass to taking out Glass-Inner

* Reassembly of All part is the reverse order of disassembly.

Screw
- Terminal Block Screw : M4 X 18.
- The others : M4 X 12.

NE595R0ABSR.indb 25 2012-02-22 □□ 10:53:16

3-15 Removing Gasket-Door

WARNING

ELECTRICAL SHOCK HAZARD

Disconnect power before servicing the range. Replace all panels before operating range. Failure to do so can result in death or electrical shock.

PRECAUTION

When you work on the electric range, be careful when handling the sheet metal parts. Sharp edges may be present, and you can cut yourself if you are not careful.

Parts	Explanation Photo
Gasket door	 
	Explanation
	1. Open the oven door to its fully down position. **2.** Pull the ends of the gasket out of the liner holes. **3.** Pull the oven door gasket clips out of the holes until all of the clips are removed.
	REASSEMBLY NOTE: When you install the new gasket, make sure that all of the clips are seated in their liner holes, and that the ends of the gasket are pushed fully into their holes. Use the pointed end of a pencil to push the gasket ends into the holes.

* Reassembly of All part is the reverse order of disassembly.

Screw
- Terminal Block Screw : M4 X 18.
- The others : M4 X 12.

NE595R0ABSR.indb 26 2012-02-22 10:53:17

3-16 Removing The Panel-Side

WARNING

ELECTRICAL SHOCK HAZARD

Disconnect power before servicing the range. Replace all panels before operating range. Failure to do so can result in death or electrical shock.

PRECAUTION

When you work on the electric range, be careful when handling the sheet metal parts. Sharp edges may be present, and you can cut yourself if you are not careful.

Parts	Explanation Photo	Explanation
Panel Side		**1.** Turn off the electrical supply. **2.** Remove the oven door from the range (see page 3-10 for the procedure). **3.** Pull the range away from the wall so you can access the back of the unit. **4.** Remove the 8 screws from the rear of Panel-Side and remove Cooktop (see step 3~4 on page 3-3). **5.** Remove the (each) 3screws from the top the Panel-Side. **6.** Pull the back of the side panel out from the range approximately 10˚ **7.** Push forward and remove Panel-Side.

* Reassembly of All part is the reverse order of disassembly.

Screw
- Terminal Block Screw : M4 X 18.
- The others : M4 X 12.

NE595R0ABSR.indb 27 2012-02-22 □□ 10:53:17

4. Troubleshooting

4-1 Failure Display Codes

There is a error code and two kinds of error codes. Possible error codes during use can be checked before service.

1. Press CLOCK pad.
2. Press a number 1, 2, 3, 4 pad.
3. Press the SET/START pad.
4. Press CUSTOM COOK and number 0 pads at the same time for 2 seconds. Error codes are displayed.
5. Press number 0 pad, the latest 5 error codes can be checked. But, if the oven turns off, the stored error codes are deleted.
6. Press CLEAR/OFF pad to return to normal display mode.



Oven sensor error

Failure code	CAUSE	SOLUTION
E-27	oven sensor opened (over 2950Ω)	**1.** Disconnect power. Open the back cover. Disconnect sensor harness from control Measure sensor resistance :1080Ω at the room temperature → If there are any problems, replace oven sensor. **2.** If there is not any problem with oven sensor, Please check whether there is a damaged therminal or wire on harness. **3.** Check resistance of oven sensor connector on main PCB (Normal:2850Ω)
E-28	Oven sensor shorted. (Under 930Ω)	

NE595R0ABSR.indb 28 2012-02-22 □□ 10:53:17

4. Troubleshooting

4-1 Failure Display Codes

Safety error

Failure code	CAUSE	SOLUTION
E-08	Oven heating error	**1.** Disconnect power. Open the back cover. Disconnect sensor harness from control. Measure sensor resistance :1080Ω at the room temperature → If there are any problems, replace oven sensor. **2.** Check the broil, bake and convection heater. Check the resistance of the each heater. **3.** Check whether DLB of sub PCB, Broil, Bake and Convection heater relay are being worked normally. **4.** Check whether there is any disconnection of harness which is linked with main PCB on main PCB. **5.** Check the resistance of oven sensor connector on main PCB. (Normal : 2850Ω)
E-0A	Oven heating over	
- SE -	Shorted key	**1.** Check whether cable of keypad has been inserted into connector of main PCB. **2.** Check whether between main PCB and connector or keypad and cable have a short circuit. **3.** If there is not a problem occurred with connector on main PCB and cable of keypad, replace the main PCB.
E-0E	Door locking error	**1.** Disconnect power. Open the back cover. Check wether harness has been connected with door lock switch and motor. **2.** Confirm whether resistance value of door lock motor is to be normal one or not. **3.** With operating door lockout, measure a voltage of connector on harness which is linked with door lock motor. (Normal Voltage : AC 120V) **4.** Check whether door locking switch is being worked normally.

NE595R0ABSR.indb 29 2012-02-22 □□ 10:53:18

4. Troubleshooting

4-1 Failure Display Codes

Safety error

Failure code	CAUSE	SOLUTION
E-27	oven sensor opened (over 2950Ω)	1. After 20 seconds from starting to work of oven, buzzer is beeping 10 times long and then finally it displays “E-27” or “E-28” as Error message. 2. If a series of function for error is not performed at all, please make sure through the method of 4-1 on 28 page.
E-28	Oven sensor shorted. (Under 940Ω)	



NE595R0ABSR.indb 30 2012-02-22 □□ 10:53:19

4. Troubleshooting

4-1 Failure Display Codes

Safety error

Failure code	CAUSE	SOLUTION
E-08	oven heating error	**1.** It will display “E-08” after buzzer is beeping 10 times long if it could not reach 100˚F(38˚c) within 10 minutes during oven is working. **2.** Please make sure through the method of 4-1 on 28 page, if those series of working for informing error take long time or not functioned.
E-0A	Oven heating over	**1.** It will display “E-0A” after beeping 10 times Bz long, if temperature is more than 650˚F(343˚c) during oven is working excluding the case of self-cleaning. **2.** Please make sure through the method of 4-1 on 28 page, if those series of working for informing error take long time or not functioned.

NE595R0ABSR.indb 31 2012-02-22 □□ 10:53:19

4-1 Failure Display Codes

Safety error



Main PCB



NE595R0ABSR.indb 32 2012-02-22 □□ 10:53:20

4-1 Failure Display Codes

Failure code	CAUSE	SOLUTION
E-0E	Door locking error	*Control lockout(press cooking time and Delay start pads at the same time for 3 seconds.) When 1 minute elapsed, It will display “E-0E” after buzzer is beeping 10 times long, if locking is occurred continually, or door locking is not working during self-cleaning or steam is being operated. Please make sure through the method of 4-1 on 28 page if those series of working for informing error take long time or not functioned.



NE595R0ABSR.indb 33 2012-02-22 10:53:20

4. Troubleshooting

4-1 Failure Display Codes

Failure code	CAUSE	SOLUTION
-SE-	short key	When 10 seconds elapses, It will display “-SE-” after buzzer is beeping 10 times long if between main PCB and cable connector or keypad and cable have a short circuit. Please make sure through the method of 4-1 on 30 page if those series of working for informing error take long time or not functioned.



NE595R0ABSR.indb 34 2012-02-22 □□ 10:53:21

4-1 Failure Display Codes

Control PCB Operation

Sort of Control PCB

Main PCB



(Front)



(Back)

Membrane



NE595R0ABSR.indb 35 2012-02-22 □□ 10:53:23

4. Troubleshooting

4-1 Failure Display Codes

* Explain of primary parts of Main PCB



Explatin of the function of primary parts.

CN01	This is to supply power with primary on Low voltage transformer, and AC120V with main PCB through harness.
CN02	This is connector which is connected with Door plunger switch and Door lock switch. (COM-NO)
CN03	This is connector which is connected with oven sensor.
CN04	This is to stop operating self-cleaning and steam mode if hot indicator lamp on cooktop is lighted with being supplied with AC120V(L1, N).
CN05	This is consisted of 15 pin and take a role of getting a cable on keypad to connect with touch PCB.
CN06	This is connector which have door lock motor, cooktop warming center, and relay of oven lamp connected.
Ry-source relay(Ry01)	Circuit is designed to all relay worked after Ry-source ralay is being worked. (For safety)
DLB relay(Ry02)	Circuit is designed to have broil relay or worked after DLB relay is being worked by Double line break.
Broil Relay(Ry03), Bake Relay(RY04) Convection Relay (Ry06) and T02	Broil relay(Ry03), Bake relay(Ry04), convection relay(Ry05) will be on-off working by micom signal after DLB relay is worked. (Broil relay : It will not be problem with reversing the order in insering Black and Brown) (Bake relay : It will not be problem with reversing the order in insering Yellow and Gray) (Convection Relay : It will not be problem with reversing the order in inserting Black and Gray+Blue)
Convection Relay	It will not be problem with reversing the order in inserting Black and Gray+Blue
ZNR1	This is the element to protect main PCB, if over voltage is supplied with PCB.
IC02	This is to supply DC12V with main PCB by voltage regulator.
IC03	This is to supply DC5V with main PCB by voltage regulator.
T01 terminal	This is the terminal to supply L1 voltage(120V) with warming drawer relay(Ry06), convection relay(Ry05) (some model)

NE595R0ABSR.indb 36 2012-02-22 10:53:24

4. Troubleshooting

SYMPTOM	DIAGNOSIS	REMEDY
oven not operating (No power, No display)	* Measure an input voltage. (240/120V or 208/120V) * Measure an input voltage of terminal block.	* check circuit breaker. * Make sure that the state of wire is connected with Terminal block.
	* Measure voltage of connector(CN08,CN09) on main PCB L1~N : 120V * Measure secondary voltage of Low Voltage Transformer. 13.5V and 7V	* Replace of repair if harness has been loosen or disconnected. * Replace if resistance of Low voltage transformer primary coil is over MΩ. (Thermal Fuse out)
	* Make sure that the relay on sub PCB is being worked normally. * Make sure whether harness between connector (CN04,CN05) on sub PCB and connector (CN04,CN05) on main PCB has been loosen or disconnected.	* Replace sub PCB if relay has been damaged or there is any cracking on the sub PCB. * Repair harness is connected main PCB with sub PCB. * After confirming whether harness has been inserted into relay on sub PCB or not, take action follow as; - Replace or repair harness. - Replace or repair main PCB.
	* Measure resistance both ends of terminal on thermostat. (normal : 0 ohoms) * Check whether harness is connected terminal on thermostat has been loosen or disconnected. * Measure voltage regulator (IC02,IC03) on main PCB. - IC02 : 7812(DC 12V) - IC03 : 7805(DC 5V)	* Replace the thermostat. * Replace or repair harness. * Replace or repair after confirming the state of working of main PCB.
Oven temperature is risen slowly.	* It will display “E-08” if it fail to reach 100˚F(38˚C) within 10 minute in a state of room temperature.	* Replace after checking whether there is any problem with oven sensor. (1080Ω at the Room temperature)
	* Make sure whether harness is connected with Broil, Bake and convection heater has been loosen or disconnected.	* Repair and replace harness.
	* Make sure whether Broil, Bake, and convection heater has been disconnected.	* After taking out terminal from each heater, measure resistance of heater and then replace that if it is not a normal resistance value.
	* Make sure that heater relay and pattern on sub PCB.	* Replace or repair relay. * Replace or repair main PCB.

NE595R0ABSR.indb 37 2012-02-22 □□ 10:53:24

4. Troubleshooting

SYMPTOM	DIAGNOSIS	REMEDY
Oven temperature is risen fast.	* Check whtether temperature is risen over 400˚F(202˚C) within 10 minutes in a state of room temperature.	* Replace or repair it if relay on sub PCB or main have a short circuit.
	* Check whether harness has been misconnected or have a short circuit.	* Replace or repair harness.
	* Measure resistance values of each heater are within a normal extent or not.	* Replace heater is in a abnormal state.
The self-cleaning feature will not operate when warming center or warming drawer is on.	* This is in normal state.	* The self-cleaning feature will not operate when warming center or warming drawer is on.
Keypad is not worked normally in partially or entirely.	* Make sure that keypad cable on main PCB is in normal state.	* Replace after confirming whether it has been loosen or disconnected.
	* Make sure connector (CN06) on main PCB or PCB pattern.	* Replace or repair after confirming whether keypad cable has been loosen or disconnted.
Warmer drawer heating is not working.	* Check warmer drawer relay (Ry06) on sub PCB and terminal(T03).	* Replace terminal(T03) or relay(Ry06). * Replace main PCB.
	* Measure whether resistance value of warmer drawer heater is in normal extent or not.	* Replace warmer drawer heater.
Oven lamp is not working.	* Check the oven lamp relay (Ry09) on sub PCB and connector (CN01).	* Replace or repair if harness has been loosen or disconnected. * Replace oven lamp relay(Ry09) or Ry-source relay.(Ry01) * Replace main PCB.
	* Measure the resistance value of both ends of lamp terminal.	* Replace lamp if it has been disconnected.(120V / 40W)

NE595R0ABSR.indb 38 2012-02-22 □□ 10:53:24

4. Troubleshooting

SYMPTOM	DIAGNOSIS	REMEDY
Cooktop is not working or being occurred a abnormal working.	* Make sure that Radiant element or Infinite switch corresponded RR(Right Rear), RF(Right Front), LR(Left Rear), LF(Left Front).	* Replace Infinite switch or Radiant element.
	* Check whether harness is connected with radiant element or Infinite switch has been loosen or disconnected.	* Replace or repair harness
	* Check whether there is any crack or the area of being disconnected of harness.	
	* Measure whether RC(Rear Center) Heater has been connected with warming center relay(Ry07) on sub PCB normally or not.	* Replace or repair Warming Center. relay(Ry07) * Replace or repair Warming Ry-source relay. * Replace sub PCB. * Replace or repair if harness has been loosen or disconnected.
Convection fan is not rotated.	* Check whether Convection fan relay (Ry08) on sub PCB and connector(CN01) is in normal.	* Replace or repair Relay. * Replace or repair connector.
	* Make sure whether harness between connector(CN04, CN05) on sub PCB and connector(CN04, CN05) on main PCB has been connected normally.	* Replace or repair harness. * Replace or repair connector. * Replace main PCB.
It has smell or smoke when oven has been started initially.	* This is in normal state.	* It has smell or smoke with burning dirt in oven or a foreign substance when oven has been working initially. * Ventilate after getting self cleaning mode to work.
LED display is a little bit dim partially or invisible entirely.	* LED display is inferior.	* Replace main PCB.
There is not buzzer beep sound when keypad is being worked.	* Check the state of buzzer on main PCB and whether PCB pattern have a short circuit or has been open.	* Replace or repair main PCB.

NE595R0ABSR.indb 39 2012-02-22 □□ 10:53:24

4-2 Electrical Malfunction

Safety error



NE595R0ABSR.indb 40 2012-02-22 □□ 10:53:26

4-2 Electrical Malfunction

* Measure resistance and voltage of Low voltage Transformer (please refer to Fig.1)



Fig.1 : Low voltage Transformer

No	voltage	resistance
Primary	120V (input)	110 ~ 120Ω
Secondary 1	13.5V	1.5 ~ 2.5
Secondary 2	7V	1.7 ~ 2.0

*Check whether primary resistance of Low voltage Transformer is in normal.

No → *Thermal Fuse with built-in Low voltage Transformer will be open if resistance is more than MΩ.

Yes → * Replace Low Voltage Transformer → END

Yes → *Measure voltage of voltage Regulator on main PCB.
IC02(7812) : DC 12V
IC03(7805) : DC 5V

Yes → * replace Main PCB. → END

NE595R0ABSR.indb 41 2012-02-22 □□ 10:53:27

4-2 Electrical Malfunction

Cooktop No heating or Abnormal working

***Single element Left Right(LR)**

LR radiant element
(No heating or
Abnormal working)

Disconnect power

*Check the LR infinite switch

*Check whether harness connected wire and the state of switch of LR infinite are in normal.

No

*Check whether harness in terminal of switch has been loosen or disconnected.

Ok

*Weld with terminal not to be misconnected if harness is disconnected from terminal on switch.

END

*Tighted terminal of harness by compressing not to be loosen.

Ok

END

Ok





Fig 2. The Infinite Switch of connected wire of harness

Position	Color	Remark
3-L1 5-L2 4-H2 2-P 1-H1	blakc+black red yellow blue+blue orange	240V,1250W NL811226 single switch Invensys Co.

Ok

*Check whether harness is connected with cooktop has been loosen or damaged.

Ok

*Check the LR Radiant element on cooktop.

Next Page

NE595R0ABSR.indb 42 2012-02-22 □□ 10:53:28

4-2 Electrical Malfunction

(Continued)

LR radiant element
(No heating or
Abnormal working)

* Check the element of LR Radiant

*Check whether harness connected wire and the state of element of LR radiant are in normal.

No

*Check whether harness in terminal of radiant has been loosen or disconnected.

Ok

*Weld with terminal not to be misconnected if harness is disconnected from terminal on radiant.

END

Ok

*Tighted terminal of harness by compressing not to be loosen.

Ok

END

Ok



Ok

*Check whether harness is connected with LR infinite switch has been damaged or disconnected.

END

WARNING

It is very dangerous when radiant heater is working in case that harness has misconnected

Fig3. LR radiant element

Position	ohms
1b-2b	∞
2a-"A"	45~50Ω

Fig4. The radiant heater of connected wire of harness

Position	color	remark
"A" 2a 1b 2b	orange yellow black+brown yellow+yellow	240V,1200W 165N-L6871R Single element Ceramaspeed Co.

NE595R0ABSR.indb 43 2012-02-22 □□ 10:53:29

4-2 Electrical Malfunction

(Continued)

Dual element Right Front(LF)





Yes

*Check whether harness is connected with cooktop has been loosen or damaged.

*Check the element of LF Radiant on cooktop.

Fig.5 The Infinite Switch of connected wire of harness

Position	Color	Remark
P1	black+black	240V,3600W dual switch Invensys Co.
S1	brown+black	
P2	red+red	
S2	blue	
4A	orange	
4	violet	
2	gray	

NE595R0ABSR.indb 44 2012-02-22 10:53:29

4-2 Electrical Malfunction

(Continued)

LF radiant element
(No heating or
Abnormal working)

*check the element of LF Radiant

*Check whether harness connected wire and the state of LF infinite switch are in normal.

No

*Check whether harness in terminal of Radiant has been loosen or disconnected.

Yes

*Tighted terminal of harness by compressing not to be loosen.

END

Yes

*Weld with terminal not to be misconnected if harness is disconnected from terminal on Radiant.

END

Ok





Ok

*Check whether harness is connected with LF infinite switch has been damaged or disconnected.

END

WARNING

It is very dangerous when radiant heater is working in case that harness has misconnected.

Fig.6 LF radiant element

Position	ohms
1b-2b	∞
2a-"A"	45~55Ω
2a-"B"	42~48Ω

(at the room temperature)

Fig.7 The radiant heater of connected wire of harness

Position	Color	Remark
"A" "B" 2a 1b 2b	blue orange gray black yellow+yellow	240V 1400/3000W Dual element Ceramaspeed Co.

NE595R0ABSR.indb 45 2012-02-22 10:53:29

4-2 Electrical Malfunction

***Single element Right Rear(RR)**

RR radiant element (No heating or abnomal working)

* Disconnect power

* Check the RR infinite switch

*Check whether harness connected wire and the state of switch of RR Radiant are in normal.

No

*Check whether harness in terminal on switch has been loosen or disconnected.

Ok

*Tighted terminal of harness by compressing not to be loosen.

Ok

END

Ok

*Weld with terminal not to be misconnected if harness is disconnected from terminal on switch.

END

Ok





Ok

*Check whether harness is connected with cooktop has been damaged or disconnected.

*Check the element of RR Radiant on Cooktop.

Next Page

Fig.8 The Infinite Switch of connected wire of harness

Position	Color	Remark
3-L1	blakc+black	240V,1250W single switch Invensys Co.
5-L2	red	
4-H2	yellow	
2-P	blue+blue	
1-H1	orange	

NE595R0ABSR.indb 46 2012-02-22 10:53:30

4-2 Electrical Malfunction

(Continued)

RR radiant element
(No heating or
Abnormal working)

*Check the element of RR Radiant

*Check whether harness connected wire and the state of element of RR Radiant are in normal.

No

*Check whether harness in terminal of Radiant has been loosen or disconnected.

Ok

*Tighted terminal of harness by compressing not to be loosen.

Ok

END

Ok

*Weld with terminal not to be misconnected if harness is disconnected from terminal on Radiant.

END

Ok





Ok

*Check whether harness is connected with RR infinite switch has been damaged or disconnected.

WARNING

It is very dangerous when radiant heater is working in case that harness has misconnected.

Fig.9 RR radiant element

Position	ohms
1b-2b	∞
2a-"A"	45~50Ω

Fig.10 The radiant heater of connected wire of harness

Position	Color	Remark
"A"	orange	240V,1200W 165N-L6871R Single element Ceramaspeed Co.
2a	yellow	
1b	black+brown	
2b	yellow+yellow	

NE595R0ABSR.indb 47 2012-02-22 □□ 10:53:30

4-2 Electrical Malfunction

(Continued)

Dual element Right Front(RF)

RF radiant element (No heating or abnomal working)

* Disconnect power

* Check theRF infinite switch

*Check whether harness connected wire and the state of RF infinite switch are in normal

No

*Check whether harness in terminal of switch has been loosen or disconnected.

Yes

*Tighted terminal of harness by compressing not to be loosen.

Yes

END

Yes

*Weld with terminal not to be misconnected if harness is disconnected from terminal on switch.

END



Yes

*Check whether harness is connected with cooktop has been loosen or damaged.

*Check the element of RF Radiant on cooktop.

Fig.5 The radiant heater of connected wire of harness

Position	Color	Remark
P1	black+black	240V,3600W dual switch Invensys Co.
S1	brown+black	
P2	red+red	
S2	blue	
4A	orange	
4	violet	
2	gray	

NE595R0ABSR.indb 48 2012-02-22 10:53:31

4-2 Electrical Malfunction

(Continued)

RF radiant element
(No heating or
Abnormal working)

*check the element of RF Radiant

*Check whether harness connected wire and the state of RF infinite switch are in normal.

No

*Check whether harness in terminal of Radiant has been loosen or disconnected.

Yes

*Tighted terminal of harness by compressing not to be loosen.

END

Yes

*Weld with terminal not to be misconnected if harness is disconnected from terminal on Radiant.

END

Yes





Yes

*Check whether harness is connected with RF infinite switch has been damaged or disconnected.

END

WARNING

It is very dangerous when radiant heater is working in case that harness has misconnected.

Fig.6 RF radiant element

Position	ohms
1b-2b	∞
2a-"A"	45~55Ω
2a-"B"	42~48Ω

(at the room temperature)

Fig.7 The radiant heater of connected wire of harness

Position	color	remark
"A"	blue	240V 1900/3000W Dual element Ceramaspeed Co.
"B"	orange	
2a	gray	
1b	black	
2b	yellow	

NE595R0ABSR.indb 49 2012-02-22 10:53:31

4-2 Electrical Malfunction







NE595R0ABSR.indb 50 2012-02-22 10:53:34

4-2 Electrical Malfunction

Hot indicator Lamp failure (cooktop)



Fig. 16 The drawer of connected wire of harness

Position	Color
A	yellow+white or white
B	white or yellow+white

WARNING

Having a short circuit might cause fire or damage of infinite switch if harness is misconnected during cooktop is being worked.

(*Warning : Having a short circuit of harness color to be turned "Yellow+White" might cause fire or damage of infinite switch.)

NE595R0ABSR.indb 51 2012-02-22 10:53:35

4-2 Electrical Malfunction

(Continued)

RC radiant element
(No heating or
Abnormal working)

*Check element of RC radiant.

*Check whether harness connected wire and the state of element of RC radiant are in normal.

No

*Check whether harness in terminal of radiant has been loosen or disconnected.

Ok

*Tighten terminal of harness by compressing not to be loosen.

Ok

END

Ok

*Weld with terminal not to be misconnected if harness is disconnected from terminal on switch.

END

Ok



Ok

*Check whether harness is connected with warming zone relay on sub PCB has been damaged or disconnected.

Ok

END

WARNING

It is very dangerous when radiant heater is working in case that harness has misconnected.

Fig.14 RC radiant element

Position	ohms
"A"-"B"	560~600Ω
"C"-"D"	∞Ω
"E"-"F"	0Ω

(at the room temperature)

Fig.15 The drawer of connected wire of harness

Position	color	remark
"A"	violet	
"B"	violet	120V,100W
"C"	yellow	
"D"	yellow	warmer element

NE595R0ABSR.indb 52 2012-02-22 10:53:35

4-2 Electrical Malfunction

Component testing procedures

WARNING

ELECTRICAL SHOCK HAZARD

Disconnect power before servicing the range. Replace all panels before operating range. Failure to do so can result in death or electrical shock.

FIGURE	TESTS MEASURE	RESULTS
 Broil Heater	* Measure resistance values of heater's terminal after taking off harness from heater. * Measure voltage of heater's terminal after making oven work by pressing broil keypad.	* Approx : 13 ~ 16Ω (at the room temperature) * Terminal voltage of Broil heater : AC 240V * Replace or repair harness
 Bake Heater	* Measure resistance values of heater's terminal after taking off harness from heater. * Measure voltage of heater's terminal after making oven work by pressing bake keypad. (Make sure that voltage has to be measured for more than 1 minute because heater is supposed to on-off cycling work.)	* Approx : 26 ~ 30Ω (at the room temperature) * Terminal voltage of bake heater : AC 240V * Replace or repair harness
Door Lock	* Measure the state of micro switch and motor after taking off harness from the heater. * Check whether lock work normally by pressing cooking time button and delay start keypad at the same time for 3 seconds.	* Lock motor Resistance : 2500 ~ 2700Ω (at the room temperature) voltage : 120V * Micro switch COM-NO * Replace or repair if harness has been loosen or disconnected.

NE595R0ABSR.indb 53 2012-02-22 10:53:41

4-2 Electrical Malfunction

FIGURE	TESTS MEASURE	RESULTS
 Oven Lamp Socket	* First of all, make sure that lamp filament is disconnected or not. * Measure resistance socket's terminal after separating harness from heater and removing lamp. * Measure the voltage of socket's terminal after having lamp worked by pressing oven light keypad.	* Approx : ∞Ω * Terminal voltage of lamp socket : 120V * Replace or repair harness.
 Convection Fan	* Measure resistance value of Motor terminal after taking off harness from Motor. * Measure Voltage of Motor's terminal after making oven work by pressing bake keypad. (Make sure that voltage has to be measured for more than 1 minute because Fan is supposed to on-off Cycling work.)	**Approx** * Convection Fan : 20 ~ 30Ω * Sub Fan : 85 ~ 100Ω* (Upper, Lower) * Terminal Voltage of Convection Fan and Sub Fan : 120V * Replace or repair harness

NE595R0ABSR.indb 54 2012-02-22 □□ 10:53:44

4-2 Electrical Malfunction

FIGURE	TESTS MEASURE	RESULTS
LR Infinite Switch (Single)	* Check whether harness is connected with switch properly. 1-H1 : orange + violet 2-P : blue 4-H2 : yellow 5-L2 : red+red 3-L1 : black+black * Measure the voltage and resistance between terminals. (Please refer to schematic diagram) * Check whether power level is right with making LR cooktop work.	**Approx** * Resistance between terminals when switch is off : ∞Ω * When switch is on(HI) resistance H1-L1-P : 0Ω L2-H2 : 0Ω * When switch is on(HI) voltage L2=H2 ↔ H1=L1:240V L1=P ↔ LR surface Lamp :120V * Replace or repair harness
RR Infinite Switch (Single)	* Check whether harness is connected with switch properly. 1-HI : orange + violet 2-P : blue 4-H2 : yellow 5-L2 : red 3-L1 : black+black * Measure voltage and resistance between terminals. (Please refer to schematic diagram) * Check whether power level is right with making RR cooktop work.	
LF Infinite Switch	* Check whether harness is connected with switch properly. P1 : black+black S1 : brown+black P2 : red+red S2 : blue 4A : orange 4 : violet 2 : gray * Measure voltage and resistance between terminals. (Please refer to schematic diagram) * Check whether power level is right with making LF cooktop work.	**Approx** * Resistance between terminals when switch is off : ∞Ω * When switch is on(HI, Max.) P1-2-4A : 0 Ω S1-S2 : 0 Ω P2-4 : 0 Ω * When switch is on(HI, Max.) voltage P1=2=4A ↔ P2=4 : 240V S1=S2 ↔ LF suface lamp : 120V * Replace or repair harness.

NE595R0ABSR.indb 55 2012-02-22 10:53:46

4-2 Electrical Malfunction

FIGURE	TESTS MEASURE	RESULTS
RF Infinite Switch	* Check whether harness is connected with switch properly. P1 : black+black S1 : brown+black P2 : red+red S2 : blue 4A : orange 4 : violet 2 : gray * Measure voltage and resistance between terminals. (Please refer to schematic diagram) * Check whether power level is right with making RF cooktop work.	**Approx** * Resistance between terminals when switch is off : ∞Ω * When switch is on(HI, Max.) P1-2-4A : 0 Ω S1-S2 : 0 Ω P2-4 : 0 Ω * When switch is on(HI, Max.) voltage S1=S2 ↔ RF surface lamp : 120V P1=2=4A ↔ P2=4 : 240V

NE595R0ABSR.indb 56 2012-02-22 □□ 10:53:46

4-2 Electrical Malfunction

FIGURE	TESTS MEASURE	RESULTS
	* Check whether harness is connected with terminal of element properly. element terminal : orange or red 2a : yellow 1b : black+brown 2b : yellow+yellow * Measure voltage and resistance between terminals. (Please refer to schematic diagram)	**Approx** * Terminal resistance : 1b-2b= ∞Ω 2a- element terminal : 45 ~ 50Ω (at the room temperature) * Voltage which supply radiant element 2a - element terminal:240V * Replace or repair harness.
	* Check whether harness is connected with terminal of element properly. First element terminal : blue Second element terminal : orange 1b : black 2a : gray 2b : yellow+yellow * Measure voltage and resistance between terminals. (Please refer to schematic diagram)	**Approx** * Terminal resistance : 1b-2b= ∞Ω 2a-First element terminal: 45 ~ 50Ω 2a-second element terminal: 42 ~ 48Ω (at the room temperature) 2a - first or second terminal :240V * Replace or repair harness.
	* Check whether harness is connected with termial of element properly. First element terminal : blue Second element terminal : orange 1b : black 2a : gray 2b : yellow * Measure voltage and resistance between terminals. (Please refer to schematic diagram)	**Approx** * Terminal resistance : 1b-2b= ∞Ω 2a-First element terminal: 45 ~ 50Ω 2a-second element terminal: 42 ~ 48Ω (at the room temperature) 2a - first or second terminal : 240V * Replace or repair harness.
	* Check whether harness is connected with terminal of element properly. - element terminal : violet, violet (It will not be problem with reversing the order in insering yellow and red.)) 187 type TCO : yellow, yellow (It will not be problem with reversing the order in insering black and violet) * Measure voltage and resistance between terminals. (Please refer to schmatic diagram)	**Approx** * terminal resistance : 187 type TCO : ∞Ω element terminal : 560 ~ 600Ω (at t he room temperature) * element terminal : 240V * Replace or repair harness

NE595R0ABSR.indb 57 2012-02-22 □□ 10:53:49

4-2 Electrical Malfunction

FIGURE	TESTS MEASURE	RESULTS
Door plunger switch	* Check the state of working of switch. * Make sure whether wire, housing and terminal is connected with switch has been damaged or not.	Nomal open : 0Ω Nomal close : ∞Ω * Replace or repair if wire or terminal has been damaged.
Hot Surface & Surface Lamp (Back Guard)	* Measure voltage which is supplied with lamp terminal. * Check whether harness has been loosen or disconnected.	**Approx.** * Lamp voltage :120V * resistance : ∞Ω * Replace or repair if wire or terminal has been damaged.

Oven sensor resistance (Temperature vs. Sensor resistance)
Ro = 1000 Ohms (0˚C), RP = 2757 Ohms, Up = 5V, a = 0.00375

degree F	degree C	ohms	degree F	degree C	ohms
0	-17.8	932.12	113	45	1170.17
14	-10	961.86	122	50	1188.93
23	-5	980.95	212	100	1374.93
32	0	1000.00	302	150	1558.01
41	5	1019.02	392	200	1738.06
50	10	1038.02	482	250	1915.39
59	15	1056.99	572	300	2089.69
68	20	1075.92	662	350	2261.07
77	25	1094.83	752	400	2429.52
86	30	1113.71	842	450	2595.05
95	35	1132.56	932	500	2757.65
104	40	1151.38	1000	538	2878.57

NE595R0ABSR.indb 58 2012-02-22 □□ 10:53:51

5-1 PCB Diagrams (Main)

(This Document can not be used without Samsung's authorization)



No.	Parts Number	Part Name	Function and Rule
1	CN01	Power Connector	This is connector which supply AC 120V(L1~N).
2	CN02	Door s/w , Door Lock s/w Connector	This is connector which connect door switch with door lock switch.
3	CN03	Oven Sensor Connector	This is connector which is connected with oven sensor..
4	CN04	Cook Top Sensing Connector	This is connector which connect regulator-energy with sense cook-top operate.
5	CN05	Key Pad Connector	This consist of 15 pin and take a role of getting a cable on keypad to connect with touch PCB.
6	CN06	Relay Connector	This is connector which connect control relay with warming center, oven lamp,convection fan, door lock switch.
7	RY01	RY-Source Control Relay	This is relay which control source of DLB,BAKE,BROIL, W/Drawer relay.
8	RY02	DLB Relay	Circuit is designed to have broil relay or convection relay worked after DLB relay is being worked by Double line break.
9	RY03	BROIL Relay	Broil relay(Ry03), Bake relay(Ry04) will be on-off working by micom signal after DLB relay is worked.
10	RY04	BAKE Relay	(Broil relay : It will not be problem with reversing the order in insering Black and Brown)(Bake relay : It will not be problem with reversing the order in insering Yellow and Gray)
11	RY06	Convection Relay	This is relay which is connected with W/Drawer.
12	RY07	Warming Center Relay	This is relay which is connected with Warming Center.
13	RY08	Conv. Fan Relay	This is relay which is connected with Conv. Fan.
14	RY09	Lamp Relay	This is relay which is connected with Lamp.
15	RY10	Door Relay	This is relay which is connected with door lock motor.
16	T01	Convection Relay Terminal	This is the terminal to connect W/Drawer heater with W/Drawer relay.
17	T02	Live1 Terminal	This is the terminal to supply L1 voltage(120V) with warming drawer relay(Ry06)
18	IC02	DC 12V Regulator IC	This is to supply DC12V with main PCB by voltage regulator.
19	IC03	DC 5V Regulator IC	This is to supply DC5V with main PCB by voltage regulator.

2012-02-22 DD 10:53:55
NE595R0ABSR.indb 59

5-2 PCB Diagrams

(This Document can not be used without Samsung's authorization)



RY02
1) DLB Relay Terminal1
2) DLB Relay Terminal2

T01
1) Convection Relay Terminal1

T02
1) Convection Relay Terminal2

CN05
Key Pad Connector

RY04
1) BAKE Relay Terminal1
2) BAKE Relay Terminal2

CN03
1) No Use
2) GND
3) Oven Temp. Sensor
4) GND

RY03
1) BROIL Relay Terminal1
2) BROIL Relay Terminal1

CN06
1) Warming Center Relay
2) No Pin
3) Oven Lamp Relay
4) No Pin
5) W-Cook top Relay
6) No Pin
7) Door Lock Relay

CN02
1) Door Sensing 1
2) GND
3) Door Lock
4) GND
5) Door Sensing 1

CN04
1) C-TOP Sensing 1
2) No Pin
3) C-TOP Sensing 2

CN02
1) AC POWER NEUTRAL (AC120V)
2) No Pin
3) AC POWER L1 (AC120V)

2012-02-22 10:59:56
NE595R0ABSR.indb 60

6-1 Wiring Diagrams

(This Document can not be used without Samsung's authorization)

WIRING DIAGRAM

MODEL : NE595R0ABSR/AA

NOTE

1) INPUT POWER : AC240V 60Hz, 13100W, 54.5A
   1-1) OVEN HEATER. : MAX 4600W, 19.1A
   1-2) COOKTOP : MAX. 8500W, 35.4A
2) OVEN DOOR OPENED AND UNLOCKED

COLOR		COLOR	
R	RED	OR	ORANGE
W	WHITE	V	VIOLET
BL	BLUE	B	BLACK
Y	YELLOW	GY	GRAY
BR	BROWN	GR	GREEN



HEATING ELECMENTS

COOKTOP ELEMENTS		
COMPONENTS	INPUT	WATTAGE
RF RADIANT ELEMENT	240V	3000
LF RADIANT ELEMENT	240V	3000
RR RADIANT ELEMENT	240V	1200
LR RADIANT ELEMENT	240V	1200
RC WARMER ELEMENT	240V	100

OVEN HEATING ELECMENTS		
COMPONENTS	INPUT	WATTAGE
BAKE	240V	2400W
BROIL	240V	3800W
CONVECTION	240V	800W
WARM DRAWER	120V	600W

NE595R0ABSR.indb 61 2012-02-22 10:53:56

7-1 Schematic Diagrams

(This Document can not be used without Samsung's authorization)

SCHEMATIC DIAGRAM

MODEL : NE595R0AB**

NOTE

1) INPUT POWER : AC240V 60Hz, 13100W, 54.5A
   1-1) OVEN HEATER. : MAX 4600W, 19.1A
   1-2) COOKTOP ELEMENTS : MAX. 8500W, 35.4A
2) OVEN DOOR OPENED AND UNLOCKED

COLOR		COLOR	
RED	RED	ORA	ORANGE
WHT	WHITE	VIO	VIOLET
BLUE	BLUE	BLK	BLACK
YEL	YELLOW	GRAY	GRAY
SKY	SKY	GRE	GREEN
BRN	BROWN		



COOKTOP ELEMENTS		
COMPONENTS	INPUT	WATTAGE
RF DUAL ELEMENT	240V	1900W / 3000W
LF SINGLE ELEMENT	240V	1400W / 3000W
RR SINGLE ELEMENT	240V	1200W
LR SIGLE ELEMENT	240V	1200W
RC SINGLE ELEMENT	240V	100W

OVEN HEATING ELEMENTS		
COMPONENTS	INPUT	WATTAGE
BAKE	240V	2400W
BROIL	240V	3800W
CONVECTION	240V	800W

NE595R0ABSR.indb 62 2012-02-22 10:53:56

7-2 Schematic Diagrams

(This Document can not be used without Samsung's authorization)



NE595R0ABSR.indb 63 2012-02-22 10:53:57

SAMSUNG ELECTRONICS

GSPN (GLOBAL SERVICE PARTNER NETWORK)

Area	Web Site
Europe, CIS, Mideast & Africa	gspn1.samsungcsportal.com
Asia	gspn2.samsungcsportal.com
North & Latin America	gspn3.samsungcsportal.com
China	china.samsungportal.com

**This Service Manual is a property of Samsung Electronics Co.,Ltd.
Any unauthorized use of Manual can be punished under applicable International and/or domestic law.**

© Samsung Electronics Co., Ltd. February. 2012
Printed in Korea